

WATER SAFE®

ASSEMBLY INSTRUCTIONS

1. Center a minimum 4" thick concrete base around the installed device placing expansion material around the riser pipes. Recommended concrete pad sizes: **WS-1S 18" x 43"** ; **WS-2S 25" x 54"** ; **WS-1FMYA 18" x 26"** ; **WS-2FMYA 21" x 30"** ; **WS-SP1 20" x 43"**
2. Center the mounting bracket between the riser pipes, front to back and left to right. Set the enclosure over the device and into the mounting bracket to ensure correct alignment. Insert the stainless rod through the bracket and enclosure.
3. Drill 1/4" holes in concrete with masonry bit using the holes in the bracket as a guide. Insert and set hit pins.
4. Insert the bolt through the hole in the stainless steel rod and secure with the "Nylock" nut. A padlock, etc. furnished by others may also be used to secure the cover.

