



WATER SAFE® ASSEMBLY INSTRUCTIONS

FOR TWO (2) DOOR ACCESS MODELS


1. Center a minimum 6" thick concrete base around the installed device placing expansion material around risers. Place conduit (before concrete pour) when installing a CLASS I enclosure (heat required).



2. Slide side panels into end panels (matching color labels @ top). Fasten end panel to side panels thru matching predrilled holes (4 places). Place each section around BFP device as shown above, with anchoring tabs at concrete base.



3. Set roof (matching color label on side panel). Fasten roof to end panels thru matching predrilled holes (4pl.). Fasten roof to side panels (typical 4 pl.).



4. With enclosure centered around BFP device, place A.G. (alignment guide) at base. The side panels should touch A.G. at access opening when fastening outside corner tabs. The A.G. is used as a straight edge when fastening inside anchoring tabs. Drill 1/4" holes in concrete, insert anchor bolts and tighten hex nuts. DISCARD A.G. WHEN COMPLETED.

5. Set access panels and lock in place.

6. For CLASS I enclosures; follow ALL local and national electrical codes.